

Installation Instructions for the Blank Plate

The Blank plate is designed to fit the N5 / N8 extension bracket, for mounting an alternate scope to the NexStar base.

Enclosed in the kit is:

- 1 – ½” Guide pin
- 2 - 8-32 Machine screws
- 1 – Blank plate

To install the plate;

First, drill and countersink the mounting holes for your scope rings.

Then mount the scope rings and scope to the plate.

Now install the 2 8-32 machine screws in the two countersunk holes shown in the picture below. If you are using a N5 use the 2 inboard holes, N8 uses the outboard holes.

Lastly, apply Loctite thread locking compound or equivalent on the threads of the guide pin that fits your application and install the guide pin.

